



J. ROCKETT AUDIO DESIGNS




Controls

- **Phase/Vibe:** All the way left is 100% phase, all the way right is 100% vibe and anything in-between is a blend of the two. The 12:00 setting is an exact 50/50 blend so you can lean toward more vibe or more phase, whichever you prefer.
- **Focus:** There is a general arc between 10:00 and 2:00 where you get the dramatic differences but anything beyond that can be very subtle, to no effect at all, so please experiment. You will find your Leslie tones, your Univibe tones and some other craziness in-between.
- **Speed:** Controls the speed for both vibe and phase.
- **Fat:** Controls the low-end whomp. If you have the bias set super subtle you can increase the fat control to bring out the effect a bit more for a smother turnaround.

Settings

The new Tranquilizer is a swirly machine. One of our favorite effects of old was the original phase 45. We always thought it was more musical than the 90 and less “in your face”. We started out to make a recreation but then discovered features we needed. The tranquilizer is capable of classic Phase 45 sounds, classic Univibe sounds, classic Leslie sounds and classic Vibe only sounds. The key to everything morphing is in the Focus control, which is an external biasing feature. One of the things we never liked about the classic 45’s was that you could not control the low-end whomp, but you can with the Tranquilizer.

All J. Rockett Audio Designs pedals operate off of the standard BOSS type 9 volt adapter or a single 9 volt battery. The power input is a 5.5 mm x 2.1 mm jack with the positive voltage on the outer sleeve. Using an external power supply will automatically disconnect the battery. Disconnect the input jack to preserve battery life when not in use or when not used with an appropriate, external power supply.



2.1mm x 5.5 mm tip/negative plug

Warranty

J. Rockett Audio Designs LLC will repair or replace, at its discretion, defective workmanship or materials on all new J. Rockett Audio Designs products directly or through the selling dealer or an authorized service technician for one year from the date of purchase at no cost to the original purchaser. Repair and replacement parts installed will be warranted for the unexpired portion of the original warranty term.

Before sending a product in for repair, please contact us at chris@rockettpedals.com or jay@rockettpedals.com or call us at 760-419-1345.

This warranty does not cover shipping costs, product appearance or damages caused by accident, abuse, misuse or alteration. A dated sales slip or order number (issued by a tech, dealer or J. Rockett Audio Designs) must accompany a product being returned for warranty service. Repairs without a return authorization number will be refused. Please allow four (4) weeks for warranty service. For more information please contact J. Rockett Audio Designs via our website at www.rockettpedals.com or call us at 760-419-1345. No other warranty is expressed or implied.